

11. SNTP

SNTP Setup

SNTP Client Enable☒

Apply

SNTP Client Mode

anycast

SNTP Client Poll Interval

1000

(64~1024)

SNTP Client Retransmit Times

3

(1~10)

SNTP Client Retransmit Interval

30

(3~30)

SNTP Client Broadcast Delay

3

(1~9999)ms

MD5 Authentication Enable

☐

Encrypt Enable

☐

SNTP Server IP Address

0.0.0.0

(X.X.X.X)

Backup Server IP Address

0.0.0.0

(X.X.X.X)

SNTP Server Key

0

ApplyRefresh

Authentication Key List

KeyID

Key

Trusted

YES

No Authentication Key configed.

AddModifyDelDelAll

Valid Server List

Server IP

Wildcard

No Valid server configed.

AddDelDelAll

SNTP (Simple Network Time Protocol) - . SNTP 'Advanced Application - SNTP Setting'.

SNTP-: Unicast, Multicast, Broadcast, Anycast:

- Unicast - NTP-, IP- NTP- 'SNTP Server IP Address' 'Backup Server IP Adress';
- Broadcast - NTP-;
- Multicast - multicast ;
- Anycast - Unicast, IP-, NTP-.

NTP-, 'SNTP Client Poll Interval' .

i

!

: (SNTP Client Retransmit Times+1)*SNTP Client Retransmit Interval

NTP- , 'MD5 Authentication Enable' ' Authentication Key List' ID NTP-.